





CLK2 DAT2

3V8

PWDN

SDA0

SCL0

Cam_VDD

USB_ON/OFF

M2

SD 2.0

SD_VDD

SD_2.0

RST2 VDD2

SIM1

CLK

CMD

VDD

DAT3

DAT2

DAT1

VDD

DAT

CLK

RST

L3 L5

C26 C31

C28 C27

R27 R29 R33 R34

C24 C32

C23 C33

C6 C7 C5 C53 C57 C55

C8 C52

D1

U16 U17 U18

Q6 Q7